




N

3905 N. ALPINE

Hydrant → ALPINE

GUEST PARKING
ENTRANCE FROM ALPINE ST.

TENANT PARKING



9-12

TENANT PARKING

21-26

39-44

BLDG. # B
UNITS 21-44

33-38

27-32


PLAY AREA

TENANT PARKING

NO PARKING

69-74

63-68



81-86

75-80

TENANT PARKING

TENANT PARKING

ENTRANCE FROM ROSE HILL

T | GUEST PARKING

STORAGE AREA FOR
MANAGEMENTS USE ONLY

Hydrant

STAPLETON

GUEST PARKING

ENTRANCE FROM LATAH ST.

Hydrant →

Latah Village

