

HEATHERWOOD Retirement

5277 Kotanar

PARKLAND

41


80 79 78 77 76 75 74 73 72 71 STAIRS CRAFT 223 222
fe
ps
ps
fe
ps
firedoor
fe
firedoor
61 62 63 64 65 66 67 68 69 70 224 221
Rotunda
Front of Building
Exit out the Front Door
Elevator
Stairs
ps
fe
down
Don't use Elevators during an Emergency
225 220
226 219
Staging Area
All Residents and Staff shall go to the East Side of the parking lot in Front of the Building.
227 218
228 217
firedoor
fe
firedoor
fe
40 39 38 37 36 35 34 33 32 31 OFFICE LAUN. 229 216
ps
fe
ps
fe
firedoor
ps
21 22 23 24 25 26 27 28 29 30 STAIRS HSKPG elevator stairwell 230 215
Exit Routes
PS=pull station
FE=fire extinguisher
2nd floor plan